

CASTER KIT MV


P/N 840129

FOR MV MODELS



1803 S.W. Jefferson Street
 Lee's Summit, Mo. 64082-2312 / USA
 (816) 524-9666 Fax (816) 524-6983
 www.billygoat.com

PURPOSE: The caster kit is to provide added mobility and turning radius over smooth surfaces.



INSTALLATION:

Tool needed: 3/4" wrench


WARNING!

DO NOT attempt this exchange while unit is being operated.

1. Secure the unit and elevate the front so that it will be easier to remove the front wheels.
2. Remove front wheel assembly by using a 3/4" wrench to remove the nylock nut and a washer.
3. Install pre-assembled caster and be sure retaining stud lines up with the hole in the axle arm.

NOTE: There are left and right sides for casters.

4. Reuse washer and nut from the step 2 to secure in place.
5. Repeat these steps on other side.



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	840105	BRACKET CASTER LH WA MV VAC	1
2	510185	BUSHING PLASTIC 0.625 ID	4
3	840106	CASTER BRKT WA MV VAC	2
4	840108	BRACKET CASTER RH WA MV VAC	1
5	8161046	NYLON INSERT LOCKNUT, 5/8-11 UNC	2
6	790144	WHEEL 4" DIA X 2" W/SPANNER	2
7	8172013	WASHER FLAT 5/8" SAE	2
8	510149	SPANNER BUSHING W/HOLE	2